


**Pacta** 

SALICE

## **PACTA**



Pacta is a compact hinge for fall flaps which operates without the need for additional stays or cables.

Pacta confers a decelerated opening action and the fall of the door is gradual and controlled.

In the fully-open position, the door and base panel are aligned, creating a uniform and flat surface.

Available with Push self-opening system, Pacta comes in a variety of finishes. Its applications are numerous: in living room and kitchen cabinets, to create desks in children's furniture or for writing surfaces and table extensions in hotel furniture.









## **PACTA**



## **Technical information**

Hinge for flap doors with decelerated opening. Sprung closing action.

Fixing to the base of the cabinet with longitudinal snap-on mounting plate (BAPGR29/16).

Standard drilling of the door ø 35.


13 mm deep cup.


90° opening.

Fixed K = 4.5 mm.


Pacta is tested and certified to level 3 of UNI EN 15828:2010

## **Drilling patterns**






## Space needed to open the door



	T=	16	17	18	19	20	21	22	23	24	25	26	27	28
K=4.5	A=	1.3	2.1	3	3.9	4.8	5.7	6.6	7.5	8.5	9.4	10.4	11.3	12.3





## **Technical information**

## Hinge for flap doors with decelerated opening. Push opening.

Fixing to the base of the cabinet with longitudinal snap-on mounting plate (BAPGR29/16).

Standard drilling of the door ø 35.


13 mm deep cup.


90° opening.

Fixed K = 4.5 mm.


# Pacta is tested and certified to level 3 of UNI EN 15828:2010

## **Drilling patterns**






## Space needed to open the door




	T=	16	17	18	19	20	21	22	23	24	25	26	27	28
K=4.5	A=	1.3	2.1	3	3.9	4.8	5.7	6.6	7.5	8.5	9.4	10.4	11.3	12.3

## **PACTA -** Assembly instructions

## Fixing the mounting plate to the cabinet




Fixing the hinge to the door




## Mounting the door onto the cabinet


Clip the hinge arm onto the mounting plates. This operation is tool free.



## Adjustments




## Fix the security screw




## **Installing the Smove**

Clip the narrow end of the Smove into position. This operation is tool free.




## **PACTA -** Assembly instructions

Lift the flap slightly and clip the other end of the Smove into position. This operation is tool free.




## **Installing the cover**

Firstly install the cover on the hinge arm and then to the cup.



## **Dimensions**




## Assembly instructions for the central hinge


## **Application of the central hinge**

We suggest that you use the central hinge for cabinets over 900 mm width.


Install the cover cap onto the hinge according to the drawing and then screw -fix the hinge to the cabinet.




After fixing the hinge, make any adjustments required



Install the cover cap onto the hinge on the cabinet side




Overall view of the mounted system




## **PACTA** - Disassembly instructions

## **Removal of the cover**




## **Disassembly of the Smove**


Lift the flap sightly and unclip the back of the Smove using a screwdriver.




Remove the other end of the Smove.




## Remove the security screw




Unfasten the hinge from the mounting plate with a screwdriver






## PACTA - Colours of the cover

# SRX B78A1XXXX\_ White



**SRXB78AQXXXX**\_ Glossy white



SRXB78AIXXXX\_ Stainless steel




SRXB78AMXXXX\_ Grey



SRXB78ACXXXX\_ Champagne



**SRXB78A0XXXX**\_
Satin metal black




**SRXB78ANXXXX**Glossy metal black




## Colours of the cover cap for the central hinge


# FRCK59RXXX1 White




FRCK59RXXXQ Glossy white



FRCK59RXXXI Stainless steel




FRCK59RXXXM Grey




FRCK59RXXXC Champagne



FRCK59RXXX0 Satin metal black



FRCK59RXXXN Glossy metal black



## PACTA - Packing

INDUSTRIAL PACKING	PART NUMBER	CARTON	PALLET
	SPRUNG CLOSING ACTION FRBKINXXSN9  PUSH OPENING FRBKINPXSN9	1 carton contains:  18 hinges . 18 mounting plates . Fixing screws included	24 cartons

SMOVE INDUSTRIAL PACKING	PART NUMBER	CARTON	PALLET
S	DRB_XXYXI  MOVE DECELERATING STRENGTH	1 carton contains: 18 pcs.	24 cartons

COVER INDUSTRIAL PACKING	PART NUMBER	CARTON	PALLET
	SRXB78A_XXXXI  COLOUR OF THE COVER	1 carton contains: 18 covers	24 cartons

DOOR-SET PACKING	PART NUMBER	CARTON	PALLET
	SPRUNG CLOSING ACTION  FRBKFEX_SN9		
	SMOVE DECELERATING STRENGTH	1 carton contains: 2 hinges	180 cartons
	PUSH OPENING	2 mounting plates • Fixing screws and Smove included	200 02.10.10
	FRBKFEP_SN9  SMOVE DECELERATING STRENGTH		

COVER DOOR-SET PACKING	PART NUMBER	CARTON	PALLET
	SRXB78A_XXXXF  COLOUR OF THE COVER	1 carton contains: 2 covers	180 cartons

CENTRAL HINGE	PART NUMBER	CARTON	PALLET
	FRCK59RXXX  COLOUR OF THE COVER CAP  Suggested for cabinets over 900 mm width	1 carton contains:  45 hinges  45 cover caps for door  45 cover caps for cabinet  Fixing screws included	36 cartons

## **PACTA - Charts**

Charts to determine which Smove is to be used for a particular door size and weight. We recommend that all applications are verified by a practical trial.


## **DRBWXXYXI**








With particularly light doors, it may be sufficient to use only one Smove







## **DRBWXXYXI**











## **DRBIXXYXI**













## **DRBSXXYXI**













# **Magnetic Push**

## Magnetic Push - Recessed magnetic release device and retaining catches

**DPMSNB** - beige



**DPMSNG** - grey



Magnetic catch ø 10 mm, 40 mm length.

**Packing**Boxes 250 pcs.
Cartons 1.500 pcs.

**DPASNB** - beige



**DPASNG** - grey



Optional supplementary magnetic catch to increase the holding strength.

It must always be used together with the DPM. The suggested position of the DPM is the

point of pressure on the door. The DPA can be positioned at any point along the opening edge of the door.

ø 10 mm, 40 mm length.

Boxes Carton

Packing

Boxes 250 pcs. Cartons 1.500 pcs.

## **DP39XXG**



Adjustable magnetic retaining catch. ø16.6 mm

## DP28SN9



Packing

Boxes 250 pcs.

Pin-fix striker for magnetic catches. ø 11.5 mm.

## **DP38XX91**



Packing

Boxes 250 pcs.

Self-adhesive striker for magnetic catches. 20x14 mm.

## Packing


Boxes 250 pcs.

## **Release device application**

#### **Application of the standard magnetic catch**

Drill a hole Ø 10 mm and min. 40 mm depth in the top, the side or the base panel of the cabinet.

Insert the release device into the hole.



## Inserted adjustable magnetic catch


The retaining catch DP39 is itself magnetic and together with the magnetism of the release device DPM considerably increase (30%) the holding strength of the door against the cabinet side, thus avoiding accidental openings.

For the installation it is necessary to drill a hole ø15 mm and 11 mm depth in the door.

Depth adjustment from -0.5 mm to +2.5 mm.








#### **Pin-fix striker**

Apply the retaining catch to the magnetic release device. Close the door.

The point of the retaining catch will show where to insert it. Reopen the door and drive in the pin to fix in position.



## **Self-adhesive striker**


Apply the retaining catch to the magnetic release device. Remove the protective strip from the adhesive. Close the door. In this way the retaining catch is positioned on the door. Reopen the door and apply a firm pressure to the retaining catch to ensure a correct installation.

#### **ATTENTION:**

For a correct application and to ensure optimal endurance, we suggest these guidelines are followed:

- 1 clean and degrease the door surface where the retaining catch is to be installed;
- 2 remove the protective strip from the adhesive;
- 3 place the retaining catch in position, in a place that is at room temperature ≥\_10° and apply a firm pressure for 10-15 seconds.

After few seconds from the installation the retaining catch is suitable for the use. After 24h the max. hold is attained.



Notes	

Notes	

## **ARTURO SALICE S.p.A.**

VIA PROVINCIALE NOVEDRATESE, 10 22060 NOVEDRATE (COMO) ITALIA TEL. 031 790424 - FAX 031 791508 info.salice@salice.com - www.salice.com

#### **DEUTSCHE SALICE GMBH**

RUDOLF DIESEL STR. 10 74382 NECKARWESTHEIM TEL. 07133 9807-0 FAX. 07133 9807-16 info.salice@deutschesalice.de www.salice.com

## **DEUTSCHE SALICE GMBH**

VERKAUFSBÜRO NORD RINGSTRASSE 36/A30 CENTER 32584 LÖHNE TEL. 05731 15608-0 FAX. 05731 15608-10 vknord@deutschesalice.de www.salice.com

## SALICE UK LTD.

KINGFISHER WAY
HINCHINGBROOKE BUSINESS PARK
HUNTINGDON CAMBS PE 29 6FN
TEL. 01480 413831
FAX. 01480 451489
info.salice@saliceuk.co.uk
www.salice.com

#### **SALICE FRANCE S.A.R.L.**

285 RUE DE GOA ZAC LES 3 MOULINS 06600 ANTIBES TEL. 0493 330069 FAX. 0493 330141 info.salice@salicefrance.com www.salice.com

## SALICE ESPAÑA, S.L.U.

C/ AIGUAFREDA 4, P.I. AMÉTLLA PARK 08480 L'AMETLLA DEL VALLÈS (BARCELONA) TEL. 0034 938 46 88 61 info.salice@saliceespana.es www.salice.com

## SALICE PORTUGAL UNIP. LDA

**SHOWROOM:** 

TV SÁ E MELO 161 FA 4470-116 MAIA – PORTO TEL: 00351 224 154 221 Info@saliceportugal.pt www.salice.com ARMAZÉM:

VIA ROTA DOS MÓVEIS I 399 4585-325 GANDRA

#### SALICE CHINA (SHANGHAI) CO. LTD.

1st FLOOR, B1 BLDG 928 MINGZHU ROAD XUJING, QINGPU DISTRICT SHANGHAI 201702 - CHINA TEL. 021 3988 9880 FAX. 021 3988 9882 info.salice@salicechina.com www.salicechina.com

#### **SALICE INDIA PVT. LTD.**

1001 & 1002, 10TH FLOOR, CENTRUM, PLOT NO. C-3, OPP. WAGLE PRABHAG SAMITI OFFICE, MIDC AREA, WAGLE INDUSTRIAL ESTATE, THANE - 400604, MAHARASHTRA TEL. 022 20812050 info@saliceindia.com www.salice.com

#### SALICE CANADA INC.

3500 RIDGEWAY DRIVE, UNIT#1 MISSISSAUGA, ONTARIO, L5L 0B4 TEL. 905 820 8787 FAX. 905 820 7226 info.salice@salicecanada.com www.salicecanada.com

#### **SALICE AMERICA INC.**

2123 CROWN CENTRE DRIVE CHARLOTTE NC. 28227 TEL. 704 841 7810 FAX. 704 841 7808 info.salice@saliceamerica.com www.saliceamerica.com



**Digital contents**